



**P/N 91670FLT (painted) & 91670-1FLT (ceramic coated)  
FLOWTECH™ EMISSION-COMPATIBLE FORD HEADERS  
97-02 Expedition/F-150/F-250/ (no HD)  
4.6L (2 & 4 WHEEL DRIVE)  
C.A.R.B. EXEMPTION # D-115-17**

Thank you for making FLOWTECH™ HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled FLOWTECH™ to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your FLOWTECH™ exhaust system.

**WARNING! Breaking in an engine with ceramic-coated headers WILL result in damage to the coating and will VOID all warranties. Ceramic-coated headers require several heat cycles to fully cure before they will withstand extreme heat. FLOWTECH™ recommends using a cast-iron exhaust manifold or an old header to break in new engines to avoid coating damage.**

**BEFORE STARTING**

Your vehicle must be raised a minimum of 36 inches. A floor hoist is ideal, if no hoist is available, we strongly urge the use of axle stands as a safety measure.

**CAUTION! YOUR CAR SHOULD NOT BE SUPPORTED ON A BUMPER JACK.**

We recommend welding all pipe slip joints, if no welding equipment is available at the time of installation, use the furnished clamps to secure the pipes until they can be welded.

**NOTE:** Apply a small amount of anti-seize to the header bolts before installing them into the cylinder heads.

**INSTALLATION PROCEDURE – PLEASE READ CAREFULLY**

1. Disconnect the battery.
2. Unbolt the flange nuts where the manifold connects to the exhaust system.
3. Disconnect the front drive shaft (4x4 models) by removing the 4 bolts on the companion flange.
4. Remove the sheet metal screws and fasteners attaching the inner fender wells and remove the fender wells.
5. Working through the wheel well, disconnect the EGR tube and dipstick tube from the left side of the engine.
6. Remove the nuts attaching the exhaust manifold to the cylinder head and remove the manifold.
7. Remove the remaining studs from the cylinder heads, using a 1/4" drive ratchet and a 5mm socket.
8. Working through the wheel well (right side), remove the nuts from the manifold and remove the manifold
9. Remove the remaining studs from the cylinder heads using a 1/4" drive ratchet and a 5mm socket.
10. Remove the EGR fitting from the left side factory exhaust manifold and install into the new header.
11. Install the driver's side header from under the vehicle and install using the supplied bolts, gaskets, and washer.
12. Loosen the EGR tube at the EGR valve (top of engine) and install the tube to the header, tightening the EGR tube.
13. Reinstall the dipstick tube and tighten all bolts to the factory torque specifications.
14. Install the right side header through the fender well, using the supplied bolts, gaskets, and washers. Tighten all bolts to spec.
15. Reinstall the exhaust system, driveshaft, and inner fender wells.
16. When finished with the installation, give your vehicle a test drive checking carefully for any new noises. After several days of driving, re-tighten all the bolts.

Any questions? Please contact Technical Service: 1-866-GOHOLLEY or 270-781-9741. For online help, please refer to the website: [www.holley.com](http://www.holley.com).

**LIMITATION OF LIABILITY – DISCLAIMER:**

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

FLOWTECH™ makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

**THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.**

California vehicle code, sections 27156 AND 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. These FLOWTECH™ Headers have received an exemption from these code sections and are legal for sale or use in all 50 states on vehicles equipped with their original catalytic converters and all emissions equipment installed. It is illegal to remove or otherwise render inoperative any emission control device on the regulated motor vehicles.

**199R10473**

**9/13/07**