



42375 - Vehicle Wiring Installation Instructions

Mitsubishi Endeavor 2003 - 2012

1. To access vehicle tail light wiring harness plug, remove the spare tire access panel located at the rear of the vehicle. Remove the spare tire.
2. Remove the rear driver side tie down D-bracket. Lift and remove the floor panel that is next to the driver side wheel well to access the vehicle 8 pin harness plug.
3. From the spare tire area route the Hopkins® converter module 8 pin end of the wiring harness under the driver side frame channel and connect it to the 8 pin vehicle connector.
4. Secure the converter module block and harness at convenient locations between the vehicle 8 pin plug and where it exits the spare well with ny-ties provided.
5. Remove the spare tire well bulk head plug near the rear of the vehicle.
6. Route the converter module 4-pin flat extension harness with grommet thru the bulkhead opening and press the new harness grommet in place. Secure the 4-pin flat extension harness approximately 2 inches on either side of the hitch with ny-ties (provided).
7. Reinstall the floor panel, D-ring tie down, spare tire, & spare tire access panel.
8. Attach the 4-pin flat dust cover (provided) to the 4-way flat connector.
9. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
10. Plug completed wire harness into the trailer 4-way flat connector.
11. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com