

1. Remove driver and passenger tail lamp assemblies to expose the factory wiring harnesses. These harnesses should have the same connector ends as the Wiring Kit and will be connected directly to the lamp assembly.
2. Disconnect vehicle taillight wiring harnesses. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Apply a small amount of grease to all electrical connections to help prevent corrosion.
4. Route green wire Wiring Kit up from under vehicle bumper and plug into the male and female harness connectors on the passenger side. Be sure the connectors are fully inserted with locking tabs in place.
5. Route yellow wire connector along bumper to the vehicle driver's side and plug into the male and female tail lamp harness plugs.
6. Grease harness extension and plug into the Wiring Kit.
7. Ground the white wire to a clean surface on the vehicle frame using a self tapping screw or use an existing bolt.
8. Route 4-way flat to the center of vehicle and secure excess wires with cable ties.
9. Plug completed wire harness into the trailer connector.
10. Test all functions with engine running to ensure proper operation.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.
- Converter maximum load – 2.1 amps. on left and right turn (one bulb on each side).

-
1. Retire los ensamblajes de las luces traseras del lado del conductor y pasajero para exponer los arneses de cableado de la fábrica. Estos arneses deben tener los mismos extremos del conector que el kit del cableado y se conectarán directamente al ensamblaje de las luces.
 2. Desconecte los arneses del cableado de las luces traseras del vehículo. Los conectores se desconectarán al oprimir o levantar una lengüeta de cierre y luego separarlos.
 3. Aplique una pequeña cantidad de grasa a todas las conexiones eléctricas para prevenir la corrosión.
 4. Dirija el kit del cableado con el cable verde hacia arriba desde abajo del parachoques del vehículo y enchufe dentro los conectores macho y hembra del arnés en el lado del pasajero. Asegúrese que los conectores estén completamente insertados con las lengüetas sujetadoras en sitio.
 5. Dirija el conector de de cable amarillo a lo largo del parachoques al lado del conductor del vehículo y enchufe a los enchufes macho y hembra de las luces traseras.
 6. Engrase la extensión del arnés y enchufe al kit del cableado.
 7. Conecte a tierra el cable blanco a una superficie limpia en el marco del vehículo usando un tornillo de enrosque propio o un perno existente.
 8. Dirija el plano de 4 direcciones al centro del vehículo y asegure el exceso de cables con las ataduras de cables.
 9. Enchufe el arnés completo al conector del remolque.
 10. Para asegurar la operación apropiada, compruebe todas las funciones con el motor funcionando.

CONSEJOS:

- La aplicación regular de grasa a las terminales de los cables del remolque ayudará a prevenir la corrosión.
- Se puede requerir una señal de destello de alta potencia para eliminar que las luces destellen rápidamente.
- Siempre desconecte el conector del remolque de botes antes de retroceder el remolque dentro del agua.
- Carga máxima del convertidor – 2.1 amperios en la direccional izquierda y derecha (una bombilla en cada lado).