



43965 - Vehicle Wiring Installation Instructions

Kia / Hyundai

1. Locate the vehicle taillight wiring harness connector behind the rear tire of the driver side, on the outside frame rail. The connector will be similar to the one on the Hopkins T-connector.
2. Remove the protective cap and insert the T-connector into the vehicle connector. Make sure the connector is fully inserted with locking tabs in place.
3. Route the 4 flat harness below the taillight assembly to either side of the receiver hitch and secure it with provided zip ties.
4. On the driver's side, locate and secure the Hopkins® T-Connector black converter box with provided zip ties to prevent damage or rattling and being careful to avoid areas that would cut or pinch the wires.
5. Attach the provided dust cover to the 4 flat connector.
6. Apply a small amount of provided grease to the 4 flat terminals to prevent corrosion.
7. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com