



1. Open rear doors.
2. Inside van, locate wiring plugs behind each tail lamp housing
3. On the passenger's side, disconnect the 3 pin wiring connector with the green wires (A) and pull apart (Fig 1). Plug the green and brown wire wiring harness into the passenger side vehicle connectors and route to center of van (Fig. 2).
4. On the driver's side, disconnect the 3 pin wiring connector with yellow wire (B) and pull apart. Plug the yellow wire wiring harness into the driver's side vehicle connectors and route to center of van (Fig. 2).
5. Remove 6mm ground screw on driver's side of vehicle and attach the white ground wire with ring terminal (C). Replace screw.
6. With engine running, test completed wiring harness functions for proper operation.
7. Secure wires to vehicle with cable ties provided.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

1. Abra las puertas traseras.
2. Dentro de camioneta, localice los enchufes de alambrado detrás de la caja de cada una de las luces traseras.
3. En el lado del pasajero, desconecte el conector triple de cables verdes (A) y sepárelo (Fig. 1). Enchufe el arnés de cables verde y café en el conector del lado del pasajero y guíelo hacia el centro de la camioneta (Fig. 2).
4. En el lado del conductor, desconecte el conector triple de cable amarillo (B) y sepárelo. Enchufe el arnés de cable amarillo en el conector del lado del conductor y guíelo hacia el centro de la camioneta (Fig. 2).
5. Quite el tornillo de tierra de 6mm del lado del conductor y coloque el cable blanco de tierra con terminal de argolla (C), coloque nuevamente el tornillo.
6. Para asegurar la operación apropiada, compruebe todas las funciones con el motor funcionando.
7. Asegure el excedente de cable utilizando las corbatas de plástico que se proveen.

CONSEJOS:

- La aplicación regular de grasa a las terminales de los cables del remolque ayudará a prevenir la corrosión.
- Se puede requerir una señal de destello de alta potencia para eliminar que las luces destellen rápidamente.
- Siempre desconecte el conector del remolque de botes antes de retroceder el remolque dentro del agua.