



1. Locate vehicle taillight wiring harness (A). This harness will have the same connector ends as the Wiring Kit. Protective mud flaps located behind each rear tire must be lowered to expose connectors (D).
2. Disconnect vehicle taillight wiring harness. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Apply a small amount of grease to all electrical connections to help prevent corrosion.
4. Plug Wiring Kit (B and E) into the male and female harness plugs. Be sure the connectors are fully inserted with locking tabs in place.
5. Ground the white wire (C) to a clean surface on the vehicle frame using a self tapping screw or use an existing bolt.
6. Plug completed wire harness into the trailer connector (E).
7. Test all functions with engine running to ensure proper operation.

**TIPS:**

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

1. Localice el arnés de cableado de las luces traseras (A). Este arnés tendrá los mismos extremos de conectores que el kit del cableado. Guardabarros protectores localizados detrás de cada llanta posterior deben bajarse para exponer los conectores (D).
2. Desconecte el arnés de cableado de las luces traseras. Los conectores se desconectarán al oprimir o levantar la lengüeta de cierre y separarlas.
3. Aplique grasa al arnés de cables al extremo del remolque para prevenir la corrosión.
4. Enchufe el kit del cableado (B y E) en los enchufes macho y hembra del arnés. Asegúrese que los conectores estén completamente insertados con las lengüetas de cierre en su sitio.
5. Conecte a tierra el cable blanco (C) sobre una superficie limpia en el marco del vehículo usando un tornillo auto-enroscador o use un perno existente.
6. Enchufe el arnés de cableado completado al conector del remolque (E).
7. Compruebe todas las funciones con el motor corriendo para asegurar la instalación apropiada.

**CONSEJOS:**

- La aplicación regular de grasa a las terminales de los cables del remolque ayudará a prevenir la corrosión.
- Se puede requerir una señal de destello de alta potencia para eliminar que las luces destellen rápidamente.
- Siempre desconecte el conector del remolque de botes antes de retroceder el remolque dentro del agua.