

#48190

1. Remove screws and splice cover
2. Insert Wires into Quick-Fix™ 4-wire flat grooves and fully insert wires into v-shaped splices.
3. Apply terminal grease to splice area.
4. Press splice cover into place and secure with screws.
5. Verify continuity of each function. LED's should illuminate upon activation.
6. Apply terminal grease to terminals.

LOCATE WIRES BY FUNCTION ONLY

White Ground
Yellow Left turn
Green Right turn
Brown Taillight

1. Remover los tornillos y la cubierta del empalme.
2. Ensamblar los cables en el conector "Quick Fix" y presionarlo contra las terminales en "V".
3. Aplicar grasa en el área del empalme.
4. Colocar y presionar la tapa en su lugar y asegurarlo con tornillos.
5. Verificar continuidad de cada función. Los LEDs deben de encenderse en cada activación.
6. Aplicar grasa en las terminales.

LOCALICE LOS CABLES POR FUNCIÓN SOLAMENTE

Blanco Tierra
Amarillo.. Direccional izquierda
Verde Direccional derecha
Café Luces traseras