

Thank you for selecting WeatherBeater® Floor Liners from Winfield Consumer Products. Your new front floor liners are custom molded to fit your Dodge Caliber / Jeep Compass / Jeep Patriot. The liners are made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners*. *However, do not remove the factory-installed carpeting* 

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liners slick.

## INSTALLATION INSTRUCTIONS FOR YOUR DODGE CALIBER / JEEP COMPASS / JEEP PATRIOT FRONT FLOOR LINER SET





LEFT OR DRIVER'S SIDE

RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR NEW FRONT LINERS, MOVE BOTH FRONT SEATS TO THEIR MOST REARWARD POSITION. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE SEATS AS DESIRED. TAKE CARE THAT INDIVIDUAL LINERS ARE ATTACHED TO THE FACTORY FLOOR MAT HOOKS.

View the Husky Liner Lifetime Warranty at <u>www.huskyliners.com/lifetime-warranty</u> 1300\_Intallations Instructions 01\_04\_17