



X-ACT CONTOUR FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:52971

Thank you for selecting an X-act Contour™ Floor Liners from Husky Liners Inc. Your new liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR NEW FRONT LINERS, MOVE BOTH FRONT SEATS TO THE MOST REARWARD POSITION. WITH THIS DONE, INSTALL LINERS AS SHOWN IN THE IMAGES ABOVE. THE LINERS WILL ATTACH TO THE FACTORY FLOOR MAT TWIST-LOCK RETAINERS LOCATED IN THE FACTORY CARPETING. ONCE THE LINERS ARE INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED.