



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN: 5482

Thank you for selecting X-act Contour™ Floor Liners from Husky Liners. Your new second seat floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



TO EASE INSTALLATION OF YOUR NEW SECOND SEAT LINER, MOVE THE FRONT ROW SEATS COMPLETELY FORWARD PRIOR TO INSTALLING YOUR LINER. ONCE THE LINER IS IN PLACE, MOVE THE FRONT SEATS BACK TO THE DESIRED POSITION.

SOME SUBARU ASCENT MODELS HAVE A CUPHOLDER THAT FOLDS DOWN FROM THE BACK OF THE FRONT ROW CONSOLE. IF YOUR ASCENT HAS THIS OPTION, YOU WILL NEED TO TRIM YOUR LINER TO ACHIEVE THE PROPER FIT. TO TRIM, FOLLOW THE MOLDED IN STEP IN THE LINER AND REMOVE THE FRONT SECTION OF THE CENTER HUMP COVERAGE AS SHOWN ABOVE AND IN IMAGES ON THE BACK OF THIS PAGE.

