



RAM 2500/3500
WITHOUT FLARES

FRONT MUD GUARD INSTALLATION INSTRUCTIONS

Please read instructions thoroughly before installation.

Tools Required

- 7/32 Socket / Driver

Package Contents

- Driver & Passenger Side Front Mud Guard
- Instruction Sheet

Determine which mudguard you have by locating the part number molded in the mounting flange (5804 DS and 5804 PS).

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fasteners from locations A, and B.
3. Attach mud guard to front fender with factory fasteners at locations A and B; check fit and make sure mud guard is parallel to ground before tightening.

