

2500HD/3500 HD GMC Sierra

FRONT MUD GUARD INSTALLATION INSTRUCTIONS*Install Paint Protection Film before mud guards (see other side)**Please read instructions thoroughly before installation.***Tools Required**

- T20 Torx

Package Contents

- Driver and Passenger Side Front Mud Guards
- Spring Clip (Qty 2)
- Instruction Sheet

Determine which mudguard you have by locating the part number molded in the mounting flange (5829 DS and 5829 PS).

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fasteners from locations A, B, and C.
3. Attach mud guard to front fender with factory fastener at locations A, B and C. Check fit and make sure mud guard is parallel to ground before tightening. Be sure to press firmly on the area with the 3M adhesive tape to make sure adhesive is set. Install Spring Clips where shown.

