

MÖGÖ

AUTOMATS



Thank you for selecting the Cargo Liner for your BMW X3.

Your new cargo liners are custom molded to fit your specific vehicle's floor board. MÖGÖ liners are designed to take the place of your factory floor mats.

Before installation, please remove blue protective film from the stainless accents. For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, do not remove the factory-installed carpeting. Your liners are made from an engineered resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex[®], 409[®] and ArmorAll[®] type cleaners work as well.



TO INSTALL DRIVER'S SIDE LINER SIMPLY POSITION LINER IN PLACE.