

MÖGÖ
AUTOMATS



Thank you for selecting a Cargo Liner for your Q5.

Your new floor liner is custom molded to fit your specific vehicle's floor board. MÖGÖ liners are designed to take the place of your factory floor mats.

For correct fit, it is necessary to remove the factory cargo mats before installing your new cargo liner. However, do not remove the factory-installed carpeting. Your liners are made from an engineered resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex[®], 409[®] and ArmorAll[®] type cleaners work as well.



TO INSTALL CARGO LINER SIMPLY POSITION LINER IN PLACE.