



**INSTALLATION INSTRUCTIONS
FOR MOUNTING**

**PROWLER MAX WINCH TRAY 321526 ON:
2011-2016 FORD SUPER DUTY TRUCKS**

1. READ THE INSTRUCTIONS COMPLETELY AND CHECK TO MAKE SURE THAT ALL OF THE REQUIRED PARTS ARE ON HAND BEFORE STARTING THE INSTALLATION. THE CARTON SHOULD CONTAIN:

- (1) WINCH TRAY PACKAGE
 - (1) WINCH TRAY ASSEMBLY
 - (2) SPACER PLATES
 - (3) FASTENER PACKAGE

REFER TO THE INSTRUCTION SHEETS INCLUDED WITH YOUR PROWLER MAX GRILLE GUARD FOR INSTALLING THE GUARD ONTO THE VEHICLE.

2. BEFORE INSTALLING THE PROWLER MAX GUARD ONTO THE VEHICLE INSERT THE PROWLER MAX WINCH TRAY (ITEM #1) INTO THE PROWLER MAX GUARD.
3. INSTALL THE GUARD AND WINCH TRAY ONTO THE MOUNTING BRACKETS, WITH THE BRACKETS TO THE OUTSIDE OF THE UPRIGHTS, AND THE WINCH TRAY TO THE INSIDE OF THE UPRIGHTS.
4. ADD SPACERS (ITEM #2) AS NEEDED AND FASTEN WITH THE 1/2"-13 X 1-3/4" CARRIAGE BOLTS (ITEM #3) INCLUDED IN THE WINCH TRAY KIT (IN PLACE OF THE 1/2"-13 X 1-1/2" BOLTS FROM THE PROWLER MAX KIT), AND THE 1/2" FLAT WASHERS, 1/2" LOCK WASHERS, AND 1/2"-13 ACORN NUTS INCLUDED IN THE PROWLER MAX KIT. LEAVE LOOSE AT THIS TIME. **(USE DOUBLE FLAT WASHERS ON THE CARRAGE BOLTS IF THE ACORN NUTS BOTTOM OUT BEFORE THEY GET TIGHT.)**
5. FINISH THE INSTALLATION AS INSTRUCTED IN THE PROWLER MAX GRILLE GUARD INSTRUCTIONS.

SERVICE PARTS LIST

ITEM	PART NO.	QTY	DESCRIPTION
1	321126	1	WINCH TRAY WELDMENT
2	321126-004	2	SPACER PLATE
3	101245	4	BOLT-CARRIAGE, 1/2"-13 X 1-3/4", BZP



SERVICE PARTS LIST

MODEL NO. - 321126

