INSTALLATION INSTRUCTIONS AND PARTS LIST

440713 STAINLESS STEEL OVAL STEPS APPLICATIONS: 2001 AND NEWER GM CREW CAB PICKUPS



- 1. Read instructions completely and check to make sure that all required parts (listed on service parts list) are on hand before starting the installation.
- 2. Assemble the Oval Step assemblies and mounting brackets as follows:
 - NOTE: The 1" X 3" serial number decal is located on the front leg of the driver's side.
 - 2.1 Lay the Oval Step assemblies (item #1) on a flat surface. (Left and right side Oval Step assemblies are identical)
 - 2.2 Attach the front short bracket (item #2) and rear tall bracket (item #3) to the Oval Step assemblies as shown. Use the ¹/₂-13 X 2" hex head bolts (item #4). Torque these bolts to 65 lb. ft.

NOTE:

DUE TO EXCESSIVE THREAD LOCKER IN THE BODY MOUNT BOLT AREA ON THE 2010+ GM SILVERADO/SIERRA, USE CAUTION WHEN REMOVING THE BODY MOUNT BOLTS TO REDUCE THE RISK OF CAUSING DAMAGE TO THE THREADED INSERTS INSIDE THE VEHICLE.

- 3 Remove the four (4) applicable factory body mount bolts from the vehicle.
 - 3.1 These four (4) bolts are reused in this installation.
 - 3.2 The body mount steel washer plates, and rubber cushions are reused between the body mount and the Oval Step brackets.
- 4 Position the Oval Step up under the vehicle and attach the front and rear bracket to the body mounts with factory body mount bolts as shown.
 - 4.1 Torque all body mount bolts to 65 lb. ft.

ITEM	PART NO.	QTY	DESCRIPTION
1	108429	2	OVAL STEP ASSY-SST,440713
2	550130	2	BRKT- MTG, GM, LH/RH, FRONT
3	549077	2	BRKT- MTG, GM, LH/RH, REAR
4	104249	4	SCREW-HEX HED, 1/2" X 2", ZP

SERVICE PARTS LIST



REV B 21MAY14 REV A 03SEPT10 551756 SHEET 1 10JAN08

