## INSTALLATION INSTRUCTIONS AND PARTS LIST

APPLICATION: MODEL 571300/401300 SES/GRIP ACCESSORY BRACKET ON: 11-16 RAM CREW CAB, CHASSIS CAB DIESEL TRUCKS



- 1. READ INSTRUCTIONS COMPLETELY AND CHECK TO MAKE SURE THAT ALL REQUIRED PARTS (LISTED ON SERVICE PARTS LIST) ARE ON HAND BEFORE STARTING THE INSTALLATION.
- 2. INSTALL THE LH (DRIVER SIDE) CENTER BRACKET AS FOLLOWS.
- 3. ON THE VERTICAL WALL OF THE ROCKER PANEL, INSTALL THE T-BOLT WELMENT (ITEM #2) INTO THE LARGE OBROUND HOLE AND FISH THE OTHER END THROUGH THE 1/2" HEXAGON HOLE SHOWN IN FIG. 1. USE CAUTION NOT TO DROP THE T-BOLT INSIDE OF THE ROCKER PANEL. ATTACH THE FLAT NYLON WASHER (ITEM #4) TO THE END OF EACH BOLT. (THIS IS A RETAINER.)
- 4. POSITION THE MOUNTING BRACKET (ITEM #1) SO THAT THE HOLES IN THE BRACKETS LINE UP WITH THE THREADED STUDS ON THE INSIDE WALL OF THE ROCKER PANEL. INSTALL THE 3/8-16 SERRATED FLANGE NUTS (ITEM #3). TIGHTEN BRACKET FASTENERS TO 19 LB FT.

## SERVICE PARTS LIST

ITEM	PART NO.	QTY	DESCRIPTION
1	552146	1	BRKT-MTG, GRIP/REGAL 7, RAM DIESEL CHASSIS CAB
1	551656	1	BRKT-MTG, MS/SES, RAM DIESEL CHASSIS CAB
2	550147	1	T-BOLT WELDMENT, ZP
3	100181	2	NUT – HEX FLNG, 3/8-16, ZP
4	108442	2	WASHER – NYL, .360 X 1.5 X .032, BLK



1200 E. Birch St. Brandon, SD 57005

LEFT (DRIVER) SIDE SHOWN

Dental 20 57005

1200 E. Brits St.

552842 SHEET 2 OF 2 20NOV15