

MBRP

1370605 Installation Instructions - 2018-UP Ski-Doo 600RS

Note: Local regulations may limit or prohibit modification to your snowmobile's emissions system and/or the sound levels that it generates. It is your responsibility to be aware of restrictions that may apply to your intended use of this product.

1. Remove the side panel.
2. Remove the exhaust springs from the muffler inlet.
3. Remove the muffler retaining bolt and spring.
4. Remove the muffler from the sled making sure the gasket stays on the outlet of the expansion chamber. Remove the 3 rubber bushings from the muffler as they will be reused.
5. Insert the rubber bushings on the MBRP Powersports muffler, only 2 will be used. Be sure the bushing with the metal sleeve is installed in the upper bracket.
6. Install the MBRP Powersports muffler in the sled. Reinstall the muffler retaining bolt and spring.
7. Reinstall the exhaust springs at the inlet.
8. Reinstall the side panel.

MBRP Ltd warranty applies for a two (2) year period from the date of purchase to defects in product material and workmanship and is to the original purchaser on record and for the original vehicle for which it was designed and installed. This warranty is limited, at MBRP Ltd sole determination, to the repair or replacement of defective product only and does not include the cost of removal or re-installation, damage by accident, abuse, misuse or misapplication or any consequential damages however they may arise. Determination of warranty coverage shall be at the discretion of an authorized MBRP Ltd quality engineer.

