

MAGNAFLOW RECOMMENDS PROFESSIONAL INSTALLATION ON ALL THEIR PRODUCTS



WARNING: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

ATTENTION: Always install any supplied band or U-bolt clamps to the proper torque specifications of 40-45 ft-lb for band clamps and 30-35 ft-lb for U-bolt clamps. Over tightening will result in the clamps breaking and will NOT be warranted by MagnaFlow.

MAGNAFLOW: 1901 Corporate Centre Dr - Oceanside, CA 92056 | 1(800)990-0905 Technical Support: 1(800) 959-9226 | Email: moreinfo@magnaflow.com

XINSTALLATION INSTRUCTIONS



Step 1. Begin removal of the OEM catalytic converter by loosening the bolts that attach the brackets to the frame. Disengage all welded hangers from the rubber insulators and remove the converter. Retain all mounting hardware as it will be used to install your new system.





Step 2. Install the catalyic converter by attaching the inlet valve and brackets with the appropriate hardware. Securely engage the weld hangers into place.



Step 3. Slip on the appropriate extension pipe and secure the supplied clamp. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.

MAGNAFLOW: 1901 Corporate Centre Dr - Oceanside, CA 92056 | 1(800)990-0905 Technical Support: 1(800) 959-9226 | Email: moreinfo@magnaflow.com

21-581 3/19/19 REV 000