

## INSTALLATION INSTRUCTIONS

AnchorTrax 6' Kit is designed to provide versatility in securing payload in the bed of pick-up trucks and trailers. AnchorTrax can be installed on the bed rail or in the floor of a pick-up truck bed. Trailers have numerous installation options to fit your tie-down needs.

### TRUCK BED RAIL INSTALLATION

1. Locate the desired mounting position.
2. Clamp or hold track in position.
3. Inspect mounting locations to insure that no obstructions exist for mounting hardware. Adjust track location as necessary.



4. Accurately mark mounting locations and remove track.
5. Drill marked locations with a 9/32" drill bit.



6. Place track over predrilled holes.
7. Position back plate behind the bed rail lip and attach with provided hardware.



8. Put mounting screws through track, bed rail and back plate, then secure with lock nuts.



9. Tighten mounting screws with a 5/32" Allen wrench and 7/16" open end wrench.



10. This completes bed rail installation.

### TRUCK AND TRAILER FLOOR INSTALLATION

1. Locate desired mounting position. Special care should be taken to position mounting holes to avoid cross braces, fuel tanks, fuel lines and electrical wiring during the drilling and mounting process.
2. Accurately mark mounting locations on floor and remove track.
3. Proceed with step 5.

#### WARNING:

Follow the installation instructions carefully. Failure to do so could result in personal injury or damage to property. Locate gas tanks, fuel filler pipes, and fuel lines to avoid puncture during drilling. Inspect track for loose or damaged hardware prior to use. Replace immediately if parts are bent, damaged or deformed. Do not use this product for towing or lifting.