

Clock CJ 1976-86



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE YOU BEGIN.

- Step 1. Check original wiring to determine which wire is (+) positive and which wire is (-) negative.
- Step 2. Connect the green wire from the replacement clock to the original negative clock wire.
- Step 3. Connect the black wire from the replacement clock to the original positive clock wire.
- Step 4. Connect the brown wire from the replacement clock to the original clock lighting wire connected to the bulb.

Black to Battery (+) positive
Green to Negative (-) ground
Brown to Lighting

For Technical Assistance Contact:
OMIX-ADA Tech Support
Phone: 1-800-449-6649
Email: techsupport@omix-ada.com
Web: www.Omix-Ada.com

Copyright Omix-Ada 2011