

Jeep® Mirror Replacement Kit (Wrangler TJ - JK)

HARDWARE NOTE: (2) new 5/16" bolts have been supplied for TJ-LJ applications. JKs will reuse factory hardware.

Item List:

- | | | |
|----------------------|--------------------------|----------------|
| (1) 6" Round Mirror | (1) M8 Bolt | (1) Foam Pad |
| (1) M8 Flat Washer | (1) M8 Lock Washer | (2) 5/16" bolt |
| (1) Mounting Bracket | (1) Knob | |
| (1) Billet Bushing | (1) Universal Mirror Arm | |



Please Note: This mirror kit has been designed for passenger and driver side applications.

Step 1. Using T40 torx wrench remove two upper windshield bracket bolts (JK). For TJ remove two flush mount torx head bolts just in front of door hinge (Pic 1-2) TJ's will use new 5/16" bolts.



pic.1



pic.2



pic.3

Step 2. Install mounting bracket with welded nut facing down. (pic.3). Tighten bolts.

Step 3. Attach mirror head to flat side of arm using M8 bolt, flat washer and lock washer. (pic.4)



pic.4

Step 4. Slide bushing on to arm. Arms have 4 alignment holes for universal installation (left/right). Rotate arm to match side application (pic.5).



pic.5

Step 5. Install arm into mounting bracket. Open doors to check clearance to mirror. Tighten knob (pic.6)



pic.6

Step 6. Adjust mirror head into desired position. Tighten screws. DO NOT over tighten. Mirror head should be tight but able to be adjusted if needed (pic.7).



pic.7

NOTE: TJ applications are designed to be used with doors off. Some visibility on passenger side will be blocked if used with doors.



JK Install
pic.8



TJ-LJ Install
pic.9

Step 2. When doors are reinstalled remove mirror arm from bracket. Place bushings back into arm. Tighten knob. (pic.8-9)