

JK FRONT TUBE DOORS

Contents:

Tube Door (latches installed)	(2)
Mirror Stanchion	(2)
Adjustable Nylon Strap	(2)
Hinge Pin Brackets Left	(2)
Hinge Pin Brackets Right	(2)




! WARNING This product is intended to provide added “off-road” convenience and utility to your vehicle. This product is not intended to provide occupant containment or protection in the event of an accident or roll-over. Further, “on road” use may involve increased risk of serious injury in the event of side-impact accidents. To reduce risk from these types of injuries: Always wear seat belt and shoulder harness for all vehicle occupants. Keep arms and body inside vehicle. Drive safely, read and understand all manufacturers warnings and product instructions before installation.

1. Locate the (2) torx head bolts that secure the driver side mirror to the vehicle. With the driver window open, hold on to the mirror with one hand while loosening the torx bolts with the other hand. Be sure not to let the mirror drop after removing these bolts. Repeat for passenger side. Set mirrors aside to be re-installed on the Tube Doors. **NOTE:** If you have a 2011 and up model Wrangler and your vehicle is equipped with power mirrors, disconnect wiring at the mirror after removal.




2. Locate the driver side door strap that limits the door opening. At the end of the strap, disconnect the electrical connector by releasing the red locking tab and pulling down on the connector. Next, remove the strap from the hook located inside the vehicle. Repeat for passenger door. **NOTICE!** The door can swing open into the vehicle once the strap is released potentially causing damage to your vehicle.



3. Remove the torx nut from the bottom of each factory hinge pin. Set these nuts aside to be re-installed on the Tube Doors. To remove the factory doors, carefully lift the door upward until the hinge pins completely clear the hinges. It will be helpful to have someone else assist with this step.



4. Loosely attach Hinge Pin Brackets to Tube Doors using supplied M8 hardware.



5. To install Tube Doors, lightly lubricate the tube door hinge pins. Position the hinge pins directly above the hinges. Slowly lower the hinge pins into the door hinges. If the hinge pins do not fully seat, slowly rotate the door back and forth until hinge pins fully engage. Install torx nuts removed in the previous step.



CAUTION! To avoid risk of injury latch mechanism must be properly adjusted before use. Inspect and adjust as necessary should wear alter alignment of latch and striker. Do not use door/latch if damaged.

6. Latch the tube door on OE stricker. Tighten all loose bolts while tube door is secure to the vehicle. Open and close the door repeatedly to make sure door is secure and functioning properly. Repeat for passenger door.



7. Attach the loop of the Adjustable Nylon Strap to the hook on the Tube Door and the hook inside the vehicle. By using different loops to attach to the vehicle hook, the amount of door opening can be adjusted.



8. To install factory mirror on the Tube Doors, locate the (2) mirror mounting holes in the driver side Tube Door. Insert the mirror prongs into the mirror mounting holes. Position the mirror stanchion such that the holes align with the mirror prongs. Secure the mirrors to the Tube Doors using the factory torx bolts removed in Step 1. Repeat for passenger door. Be sure to adjust mirrors for optimal viewing angles before operating vehicle. **CAUTION!** Side view mirrors are required equipment for on-road vehicles.



For assistance, please contact Omix-ADA Technical Support department
(770) 614-6101
techsupport@omix-ada.com
© Copyright 2010, Omix-Ada