



OMIX-ADA, Inc.

Part # 11651.82

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

## Hood Guard, Body Armor; JL & JLU

1. Prior to installation, wash the hood of vehicle and dry with a clean cloth. Use the alcohol pads to clean entire LEADING EDGE of hood.

**NOTE:** Temperature should be at least 60°F for proper tape adhesion.



2. Expose 2" of tape liner from each section of hood protector. Ensure you can access the free ends later.



3. Center the part on the hood. Part should be about 1/16" from hood edge on all sides.





OMIX-ADA, Inc.

Part # 11651.82

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

# Hood Guard, Body Armor; JL & JLU

4. Begin removing tape liner starting with the passenger side Center Top. Grasp the free end and pull tape gently in 6" sections. Apply even pressure with opposite hand to the hood protector while pulling tape liner. Repeat for driver side.

**NOTE:** You must apply even pressure from center section out to each end of part for proper adhesion to hood.



5. Using the same process, remove the tape liner from the center bottom of hood protector. Repeat for opposite side.



6. Again using the same process, remove tape liner from passenger side Far Side Edge of hood protector. Repeat for passenger side.





OMIX-ADA, Inc.

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

## Hood Guard, Body Armor; JL & JLU

7. Apply firm pressure along all edges of hood protector to ensure adhesion of tape to hood surface. Installation is now complete.

**NOTE:** Do not drive vehicle for 24 hours after installation. Do not wash vehicle for 72 hours after installation.

