

TUBULAR FRONT BUMPER WITH HOOP, STAINLESS, 55-06, CJ & WRANGLER



Step (1) Remove the front bumper from the vehicle.  
DO NOT DISCARD ORIGINAL HARDWARE.  
It will be reused for the new bumper installation.



Step (2) Position the new front bumper up to the frame  
and line up the holes to factory mounting  
locations. Using the stock bolts and supplied  
flat washers secure bumper to vehicle. Be sure  
to use all hardware supplied and tighten all bolts.



For Technical Assistance Contact:  
OMIX-ADA Tech Support  
Phone: 1-800-449-6649  
Email: [techsupport@omix-ada.com](mailto:techsupport@omix-ada.com)  
Web: [www.Omix-Ada.com](http://www.Omix-Ada.com)