

INSTALLATION INSTRUCTIONS

2017+ CAN-AM® MAVERICK X3® ROOF MOUNTS



PRODUCT INCLUDES:

- (1) Roof Mount (LH and RH) #41634
- * LIGHTS SOLD SEPARATELY

*THIS MOUNT FITS THE FOLLOWING LIGHTS: (1) 40" RDS-Series PRO° / E-Series PRO° / SR-Series PRO°

IMPORTANT

THANK YOU FOR PURCHASING RIGID PRODUCTS FOR YOUR VEHICLE.

Please read through all of these Instructions and tips before proceeding with the installation. We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems.

STEP 1

Remove the factory roof from vehicle.

STEP 2

Remove the factory warning sticker under the roof and drill the rivets out using a 3/16" drill bit.

See Figures 2, 2.1

FIGURE 2



FIGURE 2.1



STEP 3

Tape around the circled hole. Drill or file out the circled hole until the nubs are removed. A stepped drill bit is recommended.

See Figures 3, 3.1

FIGURE 3



FIGURE 3.1



STEP 4

Install the RIGID roof mount brackets with the provided hardware as shown. Do not fully tighten until the RIGID light bar is mounted and centered.

See Figures 4, 4.1

FIGURE 4



FIGURE 4.1



STEP 5

Once the RIGID light is installed and tight, center the light brackets and tighten bolts. Re-install the roof.

See Figure 5

FIGURE 5



Wiring: Wire your lights according to the instructions included with the light.

Take care to avoid any heat sources and sharp or abrasive surfaces.

Your installation is now complete. Welcome to the Rigid Nation!

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty

779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337 www.rigidindustries.com