



INSTALLATION INSTRUCTIONS

2017+ CAN-AM® MAVERICK X3® REVERSE MOUNT



PRODUCT INCLUDES:
(1) Reverse Light Mount #41639

* LIGHTS SOLD SEPARATELY

***THIS MOUNT FITS THE FOLLOWING LIGHTS:**
(2) SR-M Series PRO®

IMPORTANT

THANK YOU FOR PURCHASING RIGID PRODUCTS FOR YOUR VEHICLE.

Please read through all of these Instructions and tips before proceeding with the installation.

We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

**Always disconnect any power sources connected to your vehicle
before servicing fuses or electrical systems.**

STEP 1

Remove the factory rear plastic by
removing the (5) T-40 torque bolts.

See Figure 1

FIGURE 1



STEP 2

Mount the lights as shown below using the provided hardware that came with the lights. Make sure the light bracket itself is tight, once installed on the plastic, you will have to adjust and aim them properly.

See Figure 2

FIGURE 2



STEP 3

Install the RIGID bracket as shown while pulling the front plastic away from the SXS. The bracket installs between the shock mount and plastic radiator mount.

See Figure 3

FIGURE 3



STEP 4

Once the RIGID bracket and light is in place, reinstall the rear plastic using the (5) factory bolts. Adjust lights as needed. Once done with final adjustments, you have finished the installation.

Wiring: Wire your lights according to the instructions included with the light.
Take care to avoid any heat sources and sharp or abrasive surfaces.

**Your installation is now complete.
Welcome to the Rigid Nation!**

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty
779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337
www.rigidindustries.com

SR-M Series PRO, RIGID and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC,
a Delaware limited liability company d/b/a Rigid Industries.

11-12460-A