



Installation Instructions

Bracket Kit 14910

2004-2009 Nissan Titan King Cab/ Crew Cab

Parts List:

4- Drivers Brackets	4- Passenger Brackets	8- 8mm x 25.4mm Hex head bolt
16- 8mm Flat washers	8- 8mm nuts	16- 8mm lock washers
8- Top Clamps	8- 5-16" Carriage Bolts	8- 5-16" Nylock Nuts
8- 5-16" Lock washers		

Installation:

- 1 Remove contents from box and identify Drivers and Passenger brackets, marker "D" and "P".
- 2 Locate the factory threaded stud on the inside of the rocker panel. Align the slot in the top of the bracket over the stud and apply a nut, flat washer and lock washer, loosely tighten. The bracket will align with the factory pre-threaded holes along the lower portion of the pinch weld of vehicle. These may have a plastic cap that will need to be removed with a standard screwdriver. Insert the 8mm bolt, flat washer and lock washer through the lower slot in the bracket into the pre-threaded hole. Repeat for all mounting bracket locations. Be sure to hand tighten only at this point to ensure proper alignment later.
- 3 Clamp Rampage Streamline step bars to brackets using Small Clamping Top Plate brackets, 1.25" Bar mounting carriage bolts, lock washers and nylock nuts. Helpful tip: Place top plate inside of bottom of Streamline bar and rotate to line up with main bracket attached to vehicle. The center pin on top plate bracket should line up with center hole on Main Bracket for safe and secure fastening of the Streamline step bar. Failure to properly align this pin in the center hole may keep the Step Bars from being securely fastened.
- 4 After insuring that all parts are properly aligned and step bar surface is level, tighten all bolts. Repeat steps 1 through 4 for opposite side of vehicle to complete installation of Rampage Streamline Tube Steps.

Rampage Products 9225 Stellar Ct Unit "C", Corona, CA 92883

Phone: (951) 277-4949 Fax: (951) 277-2295

E-mail: info@rampageproducts.net

Web: www.rampageproducts.net