

Installation Instructions

87-95 Jeep Wrangler YJ
97-06 Jeep Wrangler TJ

I-WF-01



Window Frame

For proper installation and best possible fit, please read all instructions **BEFORE** you begin.
For technical assistance or to obtain missing parts, please call Customer Relations at 1-800-328-2409.

Important Notes

Due to the many variations in body alignments the new upper door frames will need to be fitted to your vehicle before the upper door skin is attached.

Contents

NOTE: Actual product may vary from illustration.



Driver and passenger side Window Frames (TJ)



Driver and passenger side Window Frames (YJ)

Installation Steps

1

NOTE: Installation illustrations show the TJ frame. Same steps apply for the YJ.

Install the upper door frame into the lower half door. Close the half door and check around the edges of the door frame for alignment. If adjustments are needed you will have to remove the upper door frame to make the adjustments. Do not make adjustments with the frame in the door.



To adjust the door frame properly you will need a flat even surface. To adjust the door frame away from the windshield you will need to stand the frame vertical on the ground with the windshield side on the ground. Stand on the lower portion of the frame and using slight force adjust the frame in the direction illustrated. Adjust the frame in small increments and test fit after each adjustment until the desired fit is achieved.



To adjust the door frame towards the windshield you will need to adjust in the opposite direction as illustrated using the same procedures as in step two.



800-328-2409 • Visit us at Rampageproducts.com
© 2020 Lund Motion Products, Inc. All rights reserved.
Rampage Products™ is a trademark of Lund Motion Products, Inc.