CAN-AM 2018-19 Defender Front Rack

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. Periodically check all hardware for tightness.

KIT CONTENTS:

Dr Side Bracket x1
Pass Side Bracket x1
Front Bracket x1
Basket/Rack x1

<u>Light Kit Only</u> LED Light Bar Bracket x1 LED Light Bar x1

TOOLS NEEDED:

5mm Allen Wrench 13mm Socket/Wrench T40 Torx Bit Drill 11/32" Drill Bit

HARDWARE INCLUDED:

8mm x 20mm Hex Head Bolts x6
8mm x 25mm Button Head Bolts x2
8mm x 40mm Button Head Bolts x4
8mm Flat Washers x12
8mm Lock Nuts x4
8mm Double Flag Nut x2
8mm Single Flag Nut x2
8mm Nylon Washers x2
8mm Spacers x2




Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
			00		
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs



INSTALLATION INSTRUCTIONS


- Remove the pin in the top corners of the front grille. See Photo 1.
- Remove the front grille. See Photo 2.






- Remove the 2 bolts from the center of the front bumper using a T40 torx bit and 13mm socket. **See Photo 3**. Install the side brackets by inserting the supplied double flag nut through the hole in the cage and secure with the supplied 8mm x 20mm hex bolts using a 13mm socket/wrench. See Photo 4.






- Drill through the 3rd hole in the bracket using a 11/32" drill bit. See Photo 5.
- Install the single flag nut through the hole in the cage and secure with supplied 8mm x 20mm hex bolt using a 13mm socket/wrench. See Photo 6.










- 7. Install 8mm x 40mm bolts with 1 flat washer on the outside and 1 nylon washer on the inside of the front bracket. **See Photo 7**.
- 8. Install rack to side bracket with 8mm lock nut and flat washer. See Photo 8.






- Secure using a 13mm socket/wrench and 5mm Allen wrench. See Photo 9.
- 10. Install the front bracket to the bumper with the supplied 8mm x 40mm button head bolt, flat washer, and spacer along with the stock nut using a 5mm Allen wrench and 13mm socket. **See Photo 10**.





- 11. Reinstall the grille behind the front bracket. See Photo 11.
- 12. **Without LED light bar:** Secure the rack to the front bracket using the supplied 8mm x 25mm button head bolts, flat washers and nuts using a 13mm socket/wrench and 5mm Allen wrench. **See Photo 12**.







13. **With LED light bar:** Install the light bar to the light bracket using the hardware supplied with the light and pinch the light bar bracket between the basket and the front bracket. Align the light bar bracket holes and secure using the supplied 8mm x 25mm button head bolts, flat washers and nuts using a 13mm socket/wrench and 5mm Allen wrench. **See Photo 13**.





By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.