

ROUGH COUNTRY

SUSPENSION SYSTEMS®

Nissan 2004-17 Titan Drop Steps

Thank you for choosing Rough Country.

Please read instructions before beginning installation. Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go. Also, please review the tools needed list and make sure you have all of the needed tools.

Kit Contents:

- (6) Step Brackets
- (6) 8mm x 30mm Bolt/8mm Nut Plates
- (6) 8mm Plastic Retainers
- (18) 8mm Lock Washers
- (24) 8mm Flat Washers
- (12) 8mm Nylock Nuts
- (18) 8mm x 30mm Bolts

Tools Needed:

- 13mm Socket
- 13mm Wrench
- Ratchet
- Torque Wrench

Installation Instructions

1. Using the supplied 8mm x 30mm bolt/8mm nut plate (use the plastic retainers to hold the bolt/nut plate) and 8mm hardware, attach the step to the mounting brackets. **Do Not Tighten. See Photo 1.**
2. Align the mounting brackets with the studs and mounting holes on the truck. **See Photo 2.**
3. Starting in the middle, attach to the vehicle using the supplied 8mm hardware. **Do Not Tighten.**
4. Check step alignment and tighten all hardware. Torque to 18 ft/lbs.
5. Repeat process on opposite side of the vehicle.



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

