

ROUGH COUNTRY

SUSPENSION SYSTEMS®

2009-14 F150 Ford Drop Steps

Thank you for choosing Rough Country.

Please read instructions before beginning installation. Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go. Also, please review the tools needed list and make sure you have all of the needed tools.

Kit Contents:

- (6) Step Brackets
- (6) 8mm x 30mm Bolt/8mm Nut Plates
- (6) 8mm Plastic Retainers
- (18) 8mm Lock Washers
- (24) 8mm Flat Washers
- (6) 8mm Nylock Nuts
- (12) 8mm x 25mm Bolts
- (6) 8mm x 30mm Bolts
- (12) 8mm Clip Nuts

Tools Needed:

- 13mm Wrench
- 13mm Socket
- Ratchet
- Torque Wrench

Installation Instructions

1. Using the supplied 8mm x 30mm bolt/8mm nut plate (use the plastic retainers to hold the bolt/nut plate) and hardware, attach the step to the mounting brackets. **Do Not Tighten. See Photo 1.**
2. Position step and attach to the rocker using the supplied 8mm hardware. **Do Not Tighten. See Photo 2.**
3. Attach to the pinch weld using the supplied 8mm hardware. **Do Not Tighten. See Photo 2.**
4. Check step alignment and tighten all hardware using a 13mm wrench/socket. Torque all 8mm hardware to 18 ft/lbs.
5. Repeat process on opposite side of the vehicle.

▲ NOTICE *On some model's center bracket, only the pinch weld mounting hole will line up. It is not required to use the second mounting hole on the rocker.*



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

