

JEEP®
DUAL STABILIZER KIT
INSTALLATION INSTRUCTIONS
Kit #: 7219



Part #: 7009 1 - 7400WS Stabilizer 2 - Hourglass 5/8" Bushings 1 - 142121 Sleeve (51792) 1 - P837 Tapered Stud Bag 1 - Boot & Boot Tie	Part #: 7119 1 - 7900WS Stabilizer 2 - 83161 Mounting Brackets 4 - Stem Bushings 2 - 142120 Washer/Nut Packs 2 - 5/16" x 1" x 2 1/4" U-bolts, Nuts & Washers 2 - 5/16" x 1 1/4" x 2 1/4" U-bolts, Nuts & Washers 1 - Boot & Boot Tie
--	--

1. Place wheels in straight forward position.
 2. Remove OEM Steering Stabilizer. Install NEW Stabilizer in place using hardware provided.
 3. To install 7119 Stabilizer, place boot onto stabilizer, but **do not** secure boot with boot tie at this time.
 4. Install both brackets onto each end of stabilizer using bushing & washer packs provided.
 5. Pull the stabilizer rod out EXACTLY half-way out. Stabilizer must be kept out exactly half-way during installation.
 6. Mount stabilizer in place (refer to photo). Install U-bolts (5/16" x 1 1/4" x 2 1/4" around track bar and 5/16" x 1" x 2 1/4" around tie rod assembly), but **do not** tighten yet.
- NOTE: Be sure the passenger bracket is located directly below the tie rod clamp (see arrow below.)** After brackets are in position, tighten the U-bolts.
7. Turn wheels fully to the left & right to make sure stabilizer is adjusted properly (refer to step #5.)
 8. Place boot tie around boot & secure.

