



WWW.SMITTYBILT.COM

## Installation Instructions

*Nerf-Step (Part # C0789CC, C07100CC)*

*07-08 Chevy/GMC Silverado/Sierra Crew-Cab 5 1/2 ft Bed and Extended Cab 6 1/2 Bed*

**NOTE: Carefully read entire instructions thoroughly before attempting to install this part. It is recommended to have some additional help while installing these bars.**

Parts Included	Qty	Tools Required
5/16" x 2"	12	Metal Punch and Hammer
5/16" Flat Washer	12	Drill with 3/8" bit
5/16" Lock Washer	12	1/2" Ratchet with socket or Wrench



Picture is for sample use, may not be actual bars

**STEP 1:** Identify the driver and passenger side bars. (The shorter end goes towards the front of the vehicle.)

**STEP 2:** Hold up each end to the underside of the truck. The bracket goes behind the pinch-weld just below the door. The spacer on the bracket butts up against the backside of the pinch-weld. Make sure the leading edge of the bar is approximately 3/4" back from the front wheel well opening. If you have over-sized tires you may want to move the bar up to 1 1/2" back for tire clearance.

**STEP 4:** Take a marker and mark on the outside of the pinch-weld so when the holes are drilled they will line up with the holes in the brackets. Make sure not to move the bar while marking locations. The marks must align perfectly to the spacer on the bracket.

**STEP 5:** Set the bar to the side, center punch to make a mark in the middle of the pinch-weld were the black marks are that you made in the previous step.

**For Technical Support/Warranty Information please call 310-762-9944**

**Smittybilt, 1600 Walnut Parkway, Compton, CA 90220**



WWW.SMITTYBILT.COM

## Installation Instructions

*Nerf-Step (Part # C0789CC, C07100CC)*

*07-08 Chevy/GMC Silverado/Sierra Crew-Cab 5 ½ ft Bed and Extended Cab 6 ½ Bed*

**STEP 6:** Drill the marked locations using a drill and 3/8" bit.

**STEP 7:** Hold the bar back into position and align all of the holes. Put the carriage bolts through the holes and spacers on the bracket and place a washer and nut on the backside. Install all bolts but do not tighten completely at this time.

**STEP 8:** Tighten the front bolt completely at this time, now move to the rear. Level the bar and then tighten the rear bolt completely at this time. Now tighten the remaining bolts. Make sure all bolts are tight. Installation is now complete.

### Product cleaning and maintenance instructions

**Stainless Steel Finish** – Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap, window or glass cleaner may be used to clean the finish. **Dual state powder coat finish** – Mild soap, window or glass cleaner may be used to clean the finish. In order to protect the finish, you may wax your product on a regular basis with pure carnauba automotive wax. Do not use any types of soap, polish or wax that contains abrasive that could damage the finish

### WARRANTY

Smittybilt's products are covered under the following limited warranties only. Note that the duration of the limited warranty differs according to the material and finish of the product purchased. Subject to the duration and conditions of the limited warranty stated below, Smittybilt warrants to the original retail purchaser that its products are free from defects in material and workmanship. All other warranties and representations express or implied are hereby disclaimed, including fitness for merchantability and buyer's intended use or purpose. All parts are sold "AS IS" except for the limited warranties granted herein. Buyer assumes all risks as to the selection, suitability and performance of all goods and products selected. This limited warranty does not cover damage or impairment in any part due to misuse, improper installation, accident or contact with on-road or off-road hazards, product modification, improper or inadequate cleaning and/or maintenance. Smittybilt is not responsible for items damaged during shipping. This warranty is not transferable from the original buyer. For the original Buyer to be eligible for the limited warranty coverage, the Buyer must provide proof of purchase. Smittybilt strongly recommends returning the warranty registration card.

Customer's remedy hereunder shall be limited only to repair or replacement (at Smittybilt's option) of any defective part(s) returned to Smittybilt at customer's expense. The determination of whether or not a returned part is defective or subject to coverage under the limited warranties stated herein shall be made at Smittybilt's sole discretion.

#### **1. Limited Lifetime Warranty on Stainless Steel Products -**

Smittybilt stainless steel products carry the foregoing limited repair or replacement warranty **against workmanship and defects in the material** so long as the original purchaser retains the original stainless steel parts.

#### **2. Limited Five (5) Year / 50,000 Mile Pro-Rata Warranty (whichever occurs first) on Dual-Stage Powder Coating Products -**

Smittybilt dual-stage powder coated products carry the foregoing limited repair or replacement warranty for a period of (5) years or 50,000 miles (whichever occurs first) from date of purchase **against workmanship and defects in the material**, provided that any claim submitted after (2.5) years from date of purchase shall, if accepted, be satisfied by Smittybilt offering customer a credit on the purchase of a replacement product equal to fifty percent (50%) of customer's initial purchase price.

Fichter Design's configuration protected by International Trade Dress Law. Fichter Designs licensed to Smittybilt Automotive Products are Protected by U.S. patent law and International Copy Right Law. US Patent #6588783 and #6874801 other patents and continuances pending. All Intellectual Property & Patent infringements will be prosecuted to the full extent of the law.

**For Technical Support/Warranty Information please call 310-762-9944**

**Smittybilt, 1600 Walnut Parkway, Compton, CA 90220**



WWW.SMITTYBILT.COM

## **Installation Instructions**

*Nerf-Step (Part # C0789CC, C07100CC)*

*07-08 Chevy/GMC Silverado/Sierra Crew-Cab 5 1/2 ft Bed and Extended Cab 6 1/2 Bed*

---

**For Technical Support/Warranty Information please call 310-762-9944**

---

**Smittybilt, 1600 Walnut Parkway, Compton, CA 90220**



WWW.SMITTYBILT.COM

## **Installation Instructions**

*Nerf-Step (Part # C0789CC, C07100CC)*

*07-08 Chevy/GMC Silverado/Sierra Crew-Cab 5 ½ ft Bed and Extended Cab 6 ½ Bed*

---

**For Technical Support/Warranty Information please call 310-762-9944**

---

**Smittybilt, 1600 Walnut Parkway, Compton, CA 90220**



WWW.SMITTYBILT.COM

## **Installation Instructions**

*Nerf-Step (Part # C0789CC, C07100CC)*

*07-08 Chevy/GMC Silverado/Sierra Crew-Cab 5 ½ ft Bed and Extended Cab 6 ½ Bed*

---

**For Technical Support/Warranty Information please call 310-762-9944**

---

**Smittybilt, 1600 Walnut Parkway, Compton, CA 90220**