



WWW.SMITYBILT.COM

Installation Instructions

Tow Hook Install

Part#7505 & 7605

NOTE: Carefully read entire instructions thoroughly before attempting to install this part. Photos are for illustration purposes and actual product may vary. Install remains the same



Item	Qty
Tow hook	1
Safety catch	1
1/2"-13x2 1/4" bolt	2
1/2"-20x2 1/4" bolt	2
1/2" Flat washer	4
1/2"-20 nut	2



WWW.SMITYBILT.COM

Installation Instructions

Tow Hook Install

Part#7505 & 7605

NOTE: Coarse and fine thread bolts are included to fit a variety of applications. If your frame is threaded, be sure to use the correct thread pitch bolts. The supplied nuts will only fit the fine thread bolts.

CJ install(76-87)

CJ models will use hole position 1&2. There are two mounting holes on top of the jeep frame, one attaches the front bumper to the frame and the other is on the front frame cover. Note: some Frame covers may have to be drilled to allow for tow hook installation.

Remove the front bumper bolt and bolt tow hook with or without safety catch to the frame using supplied bolts, flat washers and nuts. **Note:** Some frames may have threaded holes, if so, use the properly threaded bolts to thread directly into the frame. Once all bolts are in place, tighten bolts to 65 ft/lb.



YJ install

YJ Wranglers(87-95) will use hole position 1 and 3. There are two mounting holes on top of the jeep frame, one attaches the front bumper to the frame and the other is on the front frame cover. **Note:** some Frame covers may have to be drilled to allow for tow hook installation.

Remove the front bumper bolt and bolt tow hook with or without safety catch to the frame using supplied bolts and flat washers, the bolts will thread directly into the frame. Be sure to use the correct thread pitch bolt for your vehicle. Once all bolts are in place, torque bolts to 65 ft/lb. Note: on some applications there may be hardware interference between the bolt and the tubular cross member located beneath the mounting holes. If there is interference you will need to use shorter bolts for this application. 2" long grade 5 or higher bolts will need to be purchased separately from your local hardware store.

TJ install

YJ Wranglers(97-2006) will use hole position 2 and 3. There are two mounting holes on top of the jeep frame, both are used to secure the front bumper to the frame. Note: some Frame covers may have to be drilled to allow for tow hook installation.

Remove the front bumper bolt and bolt tow hook with or without safety catch to the frame using supplied bolts and flat washers, the bolts will thread directly into the frame. Be sure to use the correct thread pitch bolt for your vehicle. Once all bolts are in place, torque bolts to 65 ft/lb.