



## Installation Instructions

P/N 42725 (chrome) - P/N 42725G (bronze)

P/N 42725K (black) - P/N 42725S (silver)

### Step 1


Clean the top of the factory oil filler cap with alcohol to remove any dirt, oil or contaminants.

### Step 2

Peel the backing film off the double sided tape, then place the cap cover onto the factory cap and press firmly to set.

**ATTENTION:** Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - [Tech@spectreperformance.com](mailto:Tech@spectreperformance.com) or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.