

Installation Instructions

P/N 42726 (chrome) - P/N 42726G (bronze)

P/N 42726K (black) - P/N 42726S (silver)

Step 1


Clean the top of the factory windshield washer fluid reservoir cap with alcohol to remove any dirt, oil or contaminants.

Step 2

Peel the backing film off the double sided tape. Place the cover onto the factory washer reservoir cap and press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - Tech@spectreperformance.com or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.