



## Installation Instructions

P/N 42752 (chrome) - P/N 42752G (bronze)

P/N 42752K (black) - P/N 42752S (silver)

### Step 1

Slide the main body of the fitting cover onto the brake line. Turn the cover so the open slot is facing forward.

### Step 2

Install the retainer by inserting the bottom retainer slots into the fitting cover and then pressing firmly to clip the top tabs of the retainer into the fitting cover.

### Step 3

Rotate the fitting cover so the retainer portion is facing towards the rear of the vehicle. Press down firmly to install the fitting cover fully onto the factory brake fitting.

**ATTENTION:** Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - [Tech@spectreperformance.com](mailto:Tech@spectreperformance.com) or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

