



Installation Instructions

P/N 42921 (chrome) - P/N 42921G (bronze)

P/N 42921K (black) - P/N 42921S (silver)

Step 1

Before you permanently install the air box cover, place it onto the factory air box to ensure proper fit and alignment.

Step 2

Then clean the top of the factory air box with rubbing alcohol to remove any dirt, oil or contaminants.

Step 3

Peel the backing film off the double sided tape. Place the cover onto the air box making sure it aligns properly and press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

