

Installation Instructions

P/N 42980 (chrome) - P/N 42980G (bronze)

P/N 42980K (black) - P/N 42980S (silver)

42937

Step 1

Before you permanently install the fuse box cover, place it onto the factory fuse box lid to ensure proper fit and alignment.

Step 2

Then clean the top of the factory fuse box lid with rubbing alcohol to remove any dirt, oil or contaminants.

Step 3

Peel the backing film off the double sided tape. Place the cover onto the fuse box lid making sure it aligns properly and press firmly to set.

42922

Step 1

Place the cap cover onto the factory brake fluid reservoir cap and press firmly to install until the tabs engage fully around the stock cap.

42925

Step 1

Place the cap cover onto the factory oil cap and press firmly to install.

42926

Step 1

Place the cap cover onto the factory windshield washer fluid cap and press firmly to install until the tabs engage fully around the stock.

42933

Step 1

Place the cap cover onto the overflow cap and press firmly to install until the tabs engage fully around the stock overflow cap.

42954

Step 1

Remove the factory brake fluid reservoir cap.

Step 2

Place the cap cover onto the factory brake fluid reservoir cap and press firmly to install until the tabs engage fully around the stock cap.


42951

Step 1

Place one half of the handle cover on each side of the factory dipstick handle, then press firmly together until the cover clamps into place.

ATTENTION: Do not use harsh chemicals to clean covers.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.