

SPEED BY SPECTRE™

The 400mph Company™

p/n 92032 Wing Installation Instructions

Application: 69-70 Mustang

Made in the USA

Notes

*** We highly recommend that the installation be done by a qualified professional familiar with this type of installation**

Parts List

- 1- Wing**
- 1- Mounting bracket driver side**
- 1- Mounting bracket passenger side**
- 1- End Plate driver side**
- 1- End Plate passenger side**
- 1- Support bracket driver side**
- 1- Support bracket passenger side**
- 42- 8-32 x 1/2" stainless steel socket button head screw**
- 52- 8-32 stainless steel washer**
- 42- 8-32 stainless steel nylok nut**
- 8- 1/8" dia x 3/8" rivet**

Tools Required

- Drill**
- 1/8" Diameter drill bit**
- 5/32" Diameter drill bit**
- Rivet gun**
- 3/32" Allen**
- 11/32" Wrench**

Step 1 - Attach mounting brackets, support brackets, and end plates to wing with supplied screws, washers, and nylok nuts. End plates use two washers one the inside and one on the outside.

Step 2 - Center wing on car and mark mounting brackets hole locations.

Step 3 - Drill 1/8" holes into deck lid.

Step 4 - Remove mounting brackets from wing and attach mounting brackets to deck lid with supplied rivets.

Step 5 - Reattach wing to mounting brackets.

Step 6- Using the holes in the wing and support brackets as a guide drill 5/32" holes into deck lid.

Step 7 – Attach wing and support brackets to deck lid with supplied screws, washer and nylok nuts.

Step 8 – Adjust end plates to get parallel gap between car and end plates.

If you have any difficulties or questions regarding the installation of this product, contact the Spectre Performance Technical Department BEFORE INSTALLING THIS WING by email- tech@spectreperformance.com anytime or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.