

# SumoSprings Rear

Suspension Enhancement  
GM Colorado~Canyon 2x4/4x4 [2015]  
SumoSprings Part# SSR-212-40



SSR-212-40



Avoid wires



Bracket installation  
view inside of frame



Driver's side  
top view

**SSR-212-40 Installed**

Refer to SumoSprings application guide for part selection [www.supersprings.com](http://www.supersprings.com) [Tech line #866-898-0720]  
SumoSprings enhance load carrying capability, handling & towing. Never exceed vehicle manufacturer's GVWR rating.

## **Installation Instructions**

- 1) Park vehicle on level hard surface. Place wheel blocks in front and behind the front wheels to prevent rolling. Observe all safety precautions and wear safety glasses.
- 2) Raise the rear of the vehicle allowing the axle to hang free and rest the frame on the safety jack stands rated for the weight of the vehicle. Removal of the rear wheels will give better access but is optional.
- 3) Starting on the driver's side, at the center of the wheel well, pull back the wheel well liner right above the frame and slide in the 2 top frame brackets. Once they are located on top of the frame, slide them toward the rear of the truck a few inches. Refer to pictures on page 1 for location.
- 4) Install 4 3/8-16x4" carriage bolts into the square holes in the top frame brackets.
- 5) Remove SumoSprings parts from the box and attach the lower frame bracket plate to the top of the SumoSpring using the supplied 8mm x 25mm flat head cap screw. Prior to attachment place loc-tite on the threaded portion of the screw and secure tightly.
- 6) Attach the assembly to the underside of the frame using the 4 3/8-16x4" carriage bolts and 4 3/8-16 locking flange nuts.
- 7) **Assembly should be positioned to the rear of the OEM bumpstop, but as close to it as possible ensuring that the bolts and brackets do not interfere with wiring. See pictures on page 1 for reference.**
- 8) Tighten nuts evenly to secure to frame.
- 9) Repeat steps three through eight on the passenger's side of the vehicle.
- 10) If rear wheels were removed you can now reinstall the rear wheels and torque wheel nuts to manufacturer's spec.
- 11) Jack up vehicle, remove safety jack stands.
- 12) Remove wheel blocks from the front wheels.
- 13) Fill out warranty card and send to SuperSprings. The warranty card is an attached document.

## **Important Notice.**

- 1) For easy installation please read instructions completely first and have all necessary tools available.
- 2) We recommend that this installation be done by a professional or persons with sound mechanical knowledge.
- 3) SumoSprings are designed to work with the original factory springs only. If they have been replaced with aftermarket springs then please consult with SuperSprings International at 866-898-0720.
- 4) These instructions are meant as a guide for the installation of SumoSprings. SuperSprings International assumes no liability for the actual installation process. Installers should apply common automotive safety practices when raising, lowering and working on vehicles.
- 5) SumoSprings are designed to enhance the vehicle's load carrying performance and road handling however it does not authorize (or recommend) loading beyond the manufacturer's GVWR specifications.
- 6) For technical support contact SuperSprings International at 866-898-0720.

***To prevent damage to the vehicle and to ensure safety, do not exceed the maximum load recommended by the vehicle's manufacturer (GVWR).***