



IMPORTANT NOTICE

- ✓ For easy installation please read instructions completely first and have all necessary tools available.
- ✓ We recommend that this installation be done by a professional or persons with sound mechanical knowledge.
- ✓ SuperSway Stops are designed to work with the original factory springs only. If they have been replaced with aftermarket springs then please call SuperSprings International at 866-898-0720
- These instructions are meant as a guide for the installation of SuperSway Stops. SuperSprings International assumes no liability for the actual installation process. Installers should apply common automotive safety practices when raising, lowering and working on vehicles.
- SuperSway Stops are designed to enhance the vehicles load carrying performance and road handling however it does not authorize loading beyond the manufacturer's specifications.
- ✓ For technical support contact SuperSprings International at 866-898-0720
- To prevent damage to the vehicle and to ensure driver safety do not exceed the maximum load (GVWR) specified by the vehicle manufacturer.
- ✓ Installation Instructions

This product has been designed specifically for installation on Dodge 2500/3500 pickups and Ford F250/350/450/550 pickups and cab chassie trucks* equipped with factory overload springs and aftermarket load enhancing airbags.

Tool list

1 x Screw driver @ least 10" in overall length

1 x 3/4" wrench

Installation Instructions

1. Use the screw driver (or similar pry type tool) to remove the original rubber factory bump stops from the frame mounted overload perch.

2. Position the SuperSway Stop with the threaded stud and guide post within the slotted portion of the frame mounted overload perch.

- 3. Center the SuperSway Stop over the factory springs.
- 4. Secure the SuperSway Stop to the factory overload perch with the washer and nut provided.
- 5. Repeat the above procedure with the remaining three SuperSway Stops.

*See vehicle fit list.

SuperSprings International Inc 505 Maple Avenue, Carpinteria, CA 93013 Phone: 866-898-0720 Fax: 805-745-5553 www.supersprings.com