

# ***SIDEWIND DEFLECTOR INSTALLATION and CLEANING***

**#212**

TP-SW-BM-MOLDING

---

**This product is designed to be installed on the rubber molding surface of the door.**

- 1** Clean surface thoroughly where product is to be installed with alcohol pads provided and allow to dry.
- 2** Apply the adhesive promoter to the areas where the adhesive will make contact and allow to dry.
- 3** Slide the tab on front of the sidewind underneath the mirror base. (Some applications may require loosening the mirror base)
- 4** Peel 1" of the red backing from the adhesive strip at the rear of the sidewind and press into place.
- 5** When positioned, remove the remaining tape backing and press the part firmly along entire length of the flange using a soft cloth with a continuous rubbing motion. *BOND STRENGTH IS DEPENDENT UPON THE AMOUNT OF ADHESIVE-TO-SURFACE CONTACT. FIRM PRESSURE CREATES MAXIMUM CONTACT AND IMPROVES BOND STRENGTH. ULTIMATE BOND STRENGTH IS ACHIEVED AT 72 HOURS.*

**IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT (See Insert)!**

**IMPORTANT:** Must be cleaned with a **SOFT** cloth and soap and water **ONLY!**  
Using abrasive cleansers, chemicals or solvents will **VOID** the warranty on this product.