



INSTALLATION INSTRUCTIONS

#3125 - 2125

- 1** LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2** CLEAN THE AREA UNDER THE HOOD WITH THE ALCOHOL PAD WHERE THE TAPE IS TO ADHERE.
- 3** REMOVE THE RED BACKING FROM THE ADHESIVE TAPE ON THE HOOD PROTECTOR.
- 4** LINE UP THE HOOD PROTECTOR ON THE UNDERSIDE OF THE HOOD. PLACE A WASHER ON EACH OF THE MOUNTING SCREWS AND INSERT THE SCREWS THROUGH THE HOLES IN THE HOOD PROTECTOR INTO THE EXISTING HOLES IN THE HOOD. **TIGHTEN JUST ENOUGH TO HOLD HOOD PROTECTOR IN PLACE.**
- 5** CENTER THE HOOD PROTECTOR ON THE HOOD AND THEN TIGHTEN THE SCREWS WITH SCREWDRIVER UNTIL SNUG. **DO NOT OVER TIGHTEN** THIS MAY DAMAGE YOUR NEW HOOD PROTECTOR. CLOSE THE HOOD CAREFULLY TO CHECK THE FIT. IF THE HOOD PROTECTOR IS NOT CENTERED, SLIGHTLY LOOSEN THE SCREWS AND MOVE IT TO ONE SIDE OR THE OTHER UNTIL CENTERED AND RE-TIGHTEN THE SCREWS.
- 6** APPLY FIRM PRESSURE TO SECURELY ADHERE THE TAPED AREAS TO THE UNDERSIDE OF THE HOOD.

KIT CONTAINS:

HOOD PROTECTOR
4 MOUNTING SCREWS
2 SELF TAPPING SCREWS
6 WASHERS
1 ALCOHOL PAD

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.