

# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

## TOOLS NEEDED:

#2 PHILLIPS SCREWDRIVER

## KIT CONTAINS:

HOOD PROTECTOR

2 #6 x 3/4" SCREWS

2 OVERSIZED WASHERS

2 PLASTIC GROMMET NUTS

- 1** OPEN HOOD SO THE UNDERSIDE IS VISIBLE.
- 2** INSERT GROMMET NUTS INTO THE TWO OUTER-MOST HOLES ON THE UNDERSIDE OF THE HOOD.
- 3** USING THE ALCOHOL PADS FROM THE HARDWARE PACK CLEAN THE UNDERSIDE OF YOUR HOOD WHERE THE STRIPS OF DOUBLE SIDED TAPE WILL NEED TO ADHERE.
- 4** SLIDE AN OVERSIZED WASHER ONTO EACH OF THE #6 SCREWS FROM YOUR HARDWARE PACK. REMOVE THE RED BACKING FROM THE TAPE LOCATED ON THE 4 TABS OF YOUR HOOD PROTECTOR.
- 5** CAREFULLY, WITHOUT APPLYING TOO MUCH PRESSURE, CENTER THE HOOD PROTECTOR TO THE UNDERSIDE OF THE HOOD. ONCE YOU HAVE IT POSITIONED CORRECTLY APPLY PRESSURE TO THE 4 TABS TO FIRMLY ADHERE IT TO THE HOOD.
- 6** WITH A #2 PHILLIPS SCREWDRIVER CAREFULLY ATTACH THE REMAINING 2 TABS USING THE #6 SCREWS THAT YOU PLACED THE WASHERS ON. **DO NOT OVER TIGHTEN!!!**

## CAUTION!

**DO NOT ATTEMPT TO USE POWER TOOLS WHEN INSTALLING YOUR HOOD PROTECTOR.  
THIS WILL CAUSE THE THREADS TO STRIP INSIDE THE PLASTIC GROMMETS.**