



# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

#5B

- 1 Use alcohol pads to clean the top underside of the truck grille. Be sure that it is thoroughly cleaned to ensure maximum adhesion.
- 2 Do not remove the hood protector tape liner at this time. Center the hood protector on the top underside of the grille. Lightly mark at each side of the hood protector where it will be positioned. Make sure that the side edges of the protector are an equal distance from each side of the grille. The back of the hood protector should be touching the surface of the grille.
- 3 Remove the tape liner from the hood protector. Carefully position the hood protector just below the grille, within the marks. Once the protector is attached it cannot be removed without possible damage to the grille or the protector. Press the tape firmly into place. **BOND STRENGTH IS DEPENDENT UPON THE AMOUNT OF ADHESIVE-TO-TAPE SURFACE CONTACT.** FIRM PRESSURE DEVELOPS ADHESIVE CONTACT AND IMPROVES BOND STRENGTH. ULTIMATE BOND STRENGTH IS ACHIEVED AT 72 HOURS. ,

**KIT CONTAINS:**  
HOOD PROTECTOR  
ALCOHOL PAD  
2 SCREWS  
2 WASHERS

OPTIONAL-As an option, we have provided two self-tapping screws and shoulder washers that can be installed in the center two holes of the protector. The tape is sufficient if installed per instructions. The hardware is for those who prefer "peace of mind" installation.

**CLEANING:** USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampee Products, Inc. • 1924 S. Washington, Blvd. • Camanche, IA. 52730 • Ph 563-259-9189 Fax 563-259-9288 • [www.stampeeproducts.com](http://www.stampeeproducts.com)

## HOOD PROTECTOR FENDER SECTION INSTALLATION INSTRUCTIONS

#5

### **KIT CONTAINS:**

- 2 - HOOD PROTECTOR (FENDER SECTIONS)
- 4 - PHILLIPS HEAD SCREWS
- 4 - NYLON SHOULDER WASHERS
- 2 - FASTENER CLIPS

### **TOOLS NEEDED:**

- PHILLIPS SCREWDRIVER
- POWER DRILL WITH 1/8" BIT

- 1 Remove the two side marker lights - These lights are easily removed by taking out the one screw located directly below the marker light. With this screw removed the marker light can be pulled from the side of the headlight assembly. The bulb may be removed to allow better access to the underside of the fender.
- 2 Position the fender shield so the tab is positioned under the fender above the headlight. The portion of the fender shield closest to the grille should align with the small rubber seal passing behind the grille. Move this rubber seal very gently by pulling on the two rubber plugs anchoring the seal to expose the sheet metal lip of the fender. Slide the fastener clip onto the bottom hole of the lip of the fender. Fasten with a screw with a washer attached through the rubber seal, the fender shield and into the fastener clip.
- 3 Position the tab on the shield above the headlight and mark the hole with a pencil. Using a 1/8" drill bit, drill the hole using caution as your drill bit will be positioned on an angle to correctly position this hole. Insert a screw and tighten. Repeat steps 1 & 2 for the other side.
- 4 Insert remaining plug on rubber seal in top hole of fender.

**CLEANING:** USE ONLY WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR!