



HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1** RAISE THE HOOD ON THE VEHICLE AND REMOVE DIRT OR DEBRIS IF ANY.
- 2** LOCATE THE THREE ROUND HOLES UNDER THE HOOD AND PLACE A PLASTIC GROMMET NUT INTO EACH OF THE HOLES. REMOVE THE TWO RUBBER BUMPERS ATTACHED TO THE HOOD BY TURNING THEM 90 DEGREES IN EITHER DIRECTION AND PULLING THEM OUT.
- 3** HOLD THE HOOD PROTECTOR INTO PLACE AND INSERT A SCREW WITH A WASHER INTO EACH OF THE HOLES WITH THE GROMMET NUTS. CENTER HOOD PROTECTOR ON THE HOOD, AND TIGHTEN THE SCREWS WITH SCREWDRIVER UNTIL SNUG. **DO NOT OVER TIGHTEN, THIS MAY DAMAGE YOUR NEW HOOD PROTECTOR.**
- 4** REINSTALL THE RUBBER BUMPERS INTO THE HOOD AND CLOSE THE HOOD **CAREFULLY** TO CHECK THE FIT. IF THE HOOD PROTECTOR IS NOT CENTERED, LOOSEN THE SCREWS AND MOVE TO ONE SIDE OR THE OTHER UNTIL CENTERED AND RE-TIGHTEN WITH SCREW DRIVER.

TOOLS NEEDED:
PHILLIPS SCREWDRIVER

KIT CONTENTS:
3 Grommet Nuts
3 Screws
3 Washers

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.