

# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

**IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT ! (see insert)**

- 1** Lift the hood and remove any dirt or debris.
- 2** Center the Hood Protector to the hood and mark the centers of each mounting hole with a pencil. Take note of where the adhesive tape will make contact with the hood.
- 3** Remove the Hood Protector and drill 3/32" holes at each mark. Clean the areas on the hood where the tape will adhere with the alcohol pads provided.
- 4** Remove the red backing from the adhesive tape on the Hood Protector.
- 5** Place a shoulder washer on each of the mounting screws and fasten the Hood Protector to the hood at each of the drilled holes.
- 6** Using firm pressure secure the outer mounting tabs (with the adhesive tape) to the hood.

**KIT CONTAINS:**

HOOD PROTECTOR  
4 MOUNTING SCREWS  
4 SHOULDER WASHERS  
ALCOHOL PADS

**TOOLS NEEDED:**

DRILL W/ 3/32 BIT  
#2 PHILLIPS SCREWDRIVER  
TAPE MEASURE  
PENCIL

**CLEANING:**

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.