

INSTALLATION INSTRUCTIONS

2021-2025 Tahoe/Yukon/Suburban Console Safe w/ keyed lock Console Safe #424-01

Please read and fill out the enclosed warranty registration card or register online at <https://tuffyprompts.com/help/warranty-information/warranty-registration/> to activate your warranty.

PARTS CHECKLIST



424-01 Console Safe

TOOL CHECKLIST

- 10mm SOCKET AND DRIVER

PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

- 1) Verify your vehicle is a 2021-2025 Tahoe, Yukon, or Suburban
- 2) Remove all contents from the shipping box and confirm that you have the correct safe.
- 3) Open the factory Console lid and remove all the contents including the pad at the bottom if applicable.
- 4) Remove the the (2) factory OEM bolts using the 10mm Socket and driver, and place them to the side.
- 5) With the lid open and the legs extended, place the safe into the console with the lock towards the front of the vehicle as shown in Figure 1.
- 6) Align the holes on the feet of the safe with Factory holes in the console, and re-insert the factory OEM bolts.
- 7) Tighten the factory OEM bolts using the 10mm Socket and driver.
- 8) Reinstall the mat and the contents. Make sure you keep contents below the Hinge and locking mechanisms to avoid any entanglement with these features.

FRONT OF
VEHICLE



FIGURE 1